

A blank (300) for forming a container for consumer articles comprises panels (308, 309, 312, 314) for forming corresponding walls of the container. First side panels (311) extend from the rear wall panel (312) and second side panels (310) extend from the front wall panel (308). When assembling the container, the first and the second side panels overlap to form at least part of left and right side walls. The first side panels or the second side panels or both are connected to the respective one of the rear wall panel and the front wall panel by modified edge portions (3100, 3110, 3120, 3130). The blank comprises a pair of flaps extending from the first side panels or the second side panels or both.